

# Assembly Instructions

## Installation Notice

1. This bath waste is suitable for 5~25mm bathtub thickness
2. Flush pipes to get rid of any debris blocked in pipes before installation

## Installing steps

1. Identify all components are present prior to installation
2. Fit the waste body(11) and the silicone washer (10) into the bath
3. Place the rubber washer (9) under the bath above the overflow ring(8), and secure using the backnut(6) making sure the rubber washer(7) is between the backnut and the overflow ring. Use a pure silicon sealant where necessary
4. Fit the overflow outlet parts(1,2,3 and 4) to the bath, The waste should be tightened to the bath from the back of the bath holding the round overflow plate in position,
5. Connect the overflow elbow(4) to the overflow ring (8) using the flexible tube(5)
6. Fill the bath with water and check all joints to ensure there are no leaks, This is the best done in stages starting with a small amount of water before fully filling the bath
7. Once fitting has been completed carefully clean all plated surfaces. the finished surface on this product are hard and durable and should be cleaned on a regular basis to maintain their appearance. They should only be cleaned with warm soapy water and then wiped with a dry cloth.

